

# RELEASE NOTES FOR FTD LoRAWAN868 APP FW 2.0.0 / RTU 2.0.2

## CONCERNED PRODUCTS

The following product already contains this FW version: **ARF8123AAH**

## SUMMARY

This version adds some important features:

- New "Simplified Screen" that enables to check quickly and easily the quality of the onsite network. This screen is now the main screen of the FTD.
- Add the radio link quality of the uplinks sent to the network.
- Add the possibility to download the last 100 measures of the Field Test Device directly on a computer or a smartphone through the IoT Configurator or AT commands.
- Restore the possibility to deactivate the ADR, to fix the SF and choose a value for the power transmission
- Add the possibility to activate an "Integrated antenna" mode that emulates the behavior of a device with a PCB antenna without deactivating the ADR.
- New screen to see the ongoing configuration of the device (see after how to access it).

## TABLE DES MATIÈRES

|   |          |
|---|----------|
| <b>CONCERNED PRODUCTS</b>                                   | <b>1</b> |
| <b>SUMMARY</b>  | <b>1</b> |
| <b>CHANGES COMPARED WITH FW APP VERSION 1.1.2 (8123AAG)</b> | <b>2</b> |
| 1.1 IN GENERAL  | 2        |
| 1.2 REGISTERS   | 2        |
| 1.3 UPLINKS   | 2        |

# CHANGES COMPARED WITH FW APP VERSION 1.1.2 (8123AAG)

## 1.1 In general

- New screen that displays the network quality with a 4 levels bar graph. This screen should help users that begin with LoRaWAN network and do not really know what is behind RSSI/SNR/SF values
- Based on Link margin, FTD displays now the uplink quality and its SNR value. Previously only downlink quality was displayed.
- New screen that displays main FTD settings (ADR, DUTYCYCLE, SF AUTO/MANUAL, TX POWER AUTO/MANUAL) by pressing for 2 seconds on the “screen” button.
- Possibility to deactivate main button by pressing 2 seconds on both buttons. In that case, the accelerometer is locked too and the FTD will send periodically uplinks based on register S380 value.
- New log mechanism: up to 100 measures may be stored in FTD. The user can export these measures with the IoT configurator. Measures are timestamped and localized (if GPS is ON).
- GPS screen is now displayed only if GPS is activated.
- Downlink payload screen has been removed.
- New way to inform that a downlink has not been received. In that case ‘---’ are displayed.
- Various minor bugfixes

## 1.2 Registers

- S360 (new) determines if accelerometer is activated or not (by default: off)
- S201 (new) determines Spreading Factor value to use when ADR is OFF
- S205 (new) determines the TX power to apply on uplink sending when ADR is OFF
- S231 (new) activates the “Integrated antenna” mode that is compatible with ADR mechanism. In that case downlink quality is not displayed. This register is OFF by default.
- S382: confirmed mode is now OFF by default.

You can find all the related information in the User Guide of the concerned product.

## 1.3 Uplinks

- No changes



## Headquarters & Warehouse

Elektrostraat 17  
NL-7483 PG Haaksbergen  
The Netherlands

T: +31 (0)53 573 33 33  
E: [info@texim-europe.com](mailto:info@texim-europe.com)  
Homepage: [www.texim-europe.com](http://www.texim-europe.com)



### The Netherlands

Elektrostraat 17  
NL-7483 PG Haaksbergen

T: +31 (0)53 573 33 33  
E: [nl@texim-europe.com](mailto:nl@texim-europe.com)



### Belgium

Zuiderlaan 14, box 10  
B-1731 Zellik

T: +32 (0)2 462 01 00  
E: [belgium@texim-europe.com](mailto:belgium@texim-europe.com)



### UK & Ireland

St Mary's House, Church Lane  
Carlton Le Moorland  
Lincoln LN5 9HS

T: +44 (0)1522 789 555  
E: [uk@texim-europe.com](mailto:uk@texim-europe.com)



### Germany - North

Bahnhofstrasse 92  
D-25451 Quickborn

T: +49 (0)4106 627 07-0  
E: [germany@texim-europe.com](mailto:germany@texim-europe.com)



### Germany - South

Martin-Kollar-Strasse 9  
D-81829 München

T: +49 (0)89 436 086-0  
E: [muenchen@texim-europe.com](mailto:muenchen@texim-europe.com)



### Austria

Warwitzstrasse 9  
A-5020 Salzburg

T: +43 (0)662 216 026  
E: [austria@texim-europe.com](mailto:austria@texim-europe.com)



### Nordic

Søndre Jagtvej 12  
DK-2970 Hørsholm

T: +45 88 20 26 30  
E: [nordic@texim-europe.com](mailto:nordic@texim-europe.com)



### Italy

Via Matteotti 43  
IT-20864 Agrate Brianza (MB)

T: +39 (0)39 9713293  
E: [italy@texim-europe.com](mailto:italy@texim-europe.com)