


USER GUIDE: 1136 4-SLOT BATTERY CHARGER



TERMS & CONDITIONS

© 2013 TSL. All rights reserved.

No part of this publication may be reproduced or used in any form, or by any electrical or mechanical means, without permission in writing from Technology Solutions (UK) Ltd. This includes electronic or mechanical means, such as photocopying, recording, or information storage and retrieval systems. The material in this manual is subject to change without notice.

Technology Solutions (UK) Ltd (TSL) reserves the right to make changes to any product to improve reliability, function, or design. TSL does not assume any product liability arising out of, or in connection with, the application or use of any product, circuit, or application described herein. No license is granted, either expressly or by implication, estoppel, or otherwise under any patent right or patent, covering or relating to any combination, system, apparatus, machine, material, method, or process in which TSL products might be used. An implied license exists only for equipment, circuits, and subsystems contained in TSL products. TSL and the TSL logo are registered trademarks of TSL. Other product names mentioned in this manual may be trademarks or registered trademarks of their respective companies and are hereby acknowledged.

All software is provided strictly on an "as is" basis. All software, including firmware, furnished to the user is on a licensed basis. TSL grants to the user a non-transferable and non-exclusive license to use each software or firmware program delivered hereunder (licensed program). Except as noted below, such license may not be assigned, sublicensed, or otherwise transferred by the user without prior written consent of TSL. No right to copy a licensed program in whole or in part is granted, except as permitted under copyright law. The user shall not modify, merge, or incorporate any form or portion of a licensed program with other program material, create a derivative work from a licensed program, or use a licensed program in a network without written permission from TSL. The user agrees to maintain TSL's copyright notice on the licensed programs delivered hereunder, and to include the same on any authorized copies it makes, in whole or in part. The user agrees not to decompile, disassemble, decode, or reverse engineer any licensed program delivered to the user or any portion thereof.

TSL reserves the right to make changes to any software or product to improve reliability, function, or design. TSL does not assume any product liability arising out of, or in connection with, the application or use of any product, circuit, or application described herein.

Symbol is a registered trademark of Motorola Technologies, Inc.

CONTENT

Introduction.....	4
Parts of the 1136 Battery Charger.....	4
Inserting and removing the battery retaining clips.....	5
Inserting and removing a battery.....	6
Connecting the power supply.....	7
Charging batteries.....	8
Troubleshooting and Maintenance.....	9
Maintenance.....	9
Troubleshooting.....	10
Technical specifications.....	11
Summary of specifications.....	11
Regulatory Information.....	12
FCC.....	12
Industry Canada.....	12
Waste Electrical and Electronic Equipment (WEEE).....	13
Warranty.....	13
About TSL.....	15
About.....	15
Contact.....	15

History

<u>Version</u>	<u>Date</u>	<u>Modifications</u>
1.0	08/08/2012	Document Creation
1.1	20/08/2012	Change to battery warning text in Regulatory Section

INTRODUCTION

The Technology Solutions 1136 4-Slot Battery Charger is intended for charging Varta Microbattery's EasyPack (EZPack L and EZPack XL) rechargeable Li-Polymer battery packs. The charger can charge up to four batteries simultaneously. The four batteries can all be the same type, or can be two of each type. The charger senses which type of battery has been inserted and adjusts the charge rate accordingly. There is an individual charge status indicator for each battery slot. The charger also monitors the temperature of each battery pack and adjusts the charge rate to provide optimal charge rate whilst maintaining safe battery temperature.

The 1136 Battery Charger is powered by a Motorola 12 V power supply, part number 50-14000-148R or PWRS-14000-148C.

PARTS OF THE 1136 BATTERY CHARGER






FIGURE 1: Parts of the 1136 Battery Charger

INSERTING AND REMOVING THE BATTERY RETAINING CLIPS


2) The hook at the top of battery retaining clip must face forwards towards the charge status indicator.

1) Align the battery retaining clip with the required slot.

3) Push the battery retaining clip down until it clicks into position.



Clip at front for EasyPack L



Clip at back for EasyPack XL

FIGURE 2: Inserting the battery retaining clips

The battery retaining clips are required to hold the battery in position during charge. The clips do not determine the charge rate, but if they are not correctly positioned then the battery will not make the necessary electrical contact and will not be charged. It is possible to have the front and back battery compartments set for the same or different battery packs. It does not matter which compartment is set for which battery type.

The clips can be inserted in one of two slots. The front slot (nearest the charge status indicator) is for the smaller EasyPack L battery. The rear slot (furthest from the charge status indicator) is for the larger EasyPack XL battery. Insert the clip with the hook at the top nearest the charge status indicator.


Push the clip vertically downwards into the appropriate slot. When it is fully inserted it will click and lock into place.

If the clip needs to be moved to reconfigure the charger, pull it vertically upwards so that it releases and then lift it out of the charger.


INSERTING AND REMOVING A BATTERY

Insertion

Insert the battery with the gold contacts next to the label facing towards the charge status indicator for that battery compartment. Slide the battery down into the compartment and push it backwards to make sure it hooks under the battery retaining clip.




Slide battery in to compartment, gold contacts and label to the front.



Ensure battery hooks under battery retaining clip.

Removal

To remove the battery, pull the top forwards towards the charge status indicator so that it is clear of the hook on the battery retaining clip. Lift the battery out of the charge compartment.



Pull the top of the battery forwards and lift the battery out of the compartment.

FIGURE 3: Inserting and removing a battery

CONNECTING THE POWER SUPPLY

Use only one of the recommended Motorola power supplies (part number 50-14000-148R or PWRS-14000-148C).

Plug the power supply into the socket on the back of the battery charger. Use an appropriate mains lead to connect the power supply to the mains. It is recommended that when the charger is not in use that the power supply is turned off and disconnected from the mains.

When the charger is powered the blue indicator on the front of the charger lights.




FIGURE 4: Battery Charger power input connector

CHARGING BATTERIES




Ensure that the battery retaining clips are positioned correctly for the required battery type (Section 3) and that the power supply is connected (Section 5).

Insert the battery or batteries (Section 4). Batteries can be inserted and removed at any time. It is not necessary to turn the charger power supply off to insert or remove a battery. Each charge compartment is independent of the others. A fully charged battery can be removed whilst other batteries are still charging. A battery can be inserted whilst other batteries are charging.

When a battery is inserted the charger senses whether it is an EasyPack L or EasyPack XL battery based on the Identification Resistor built into the battery and selects the appropriate charge rate. The charger performs a test of the battery to make sure it is safe to charge. So long as no problems are detected the charger starts to charge the battery. Charge in progress is indicated by a slow flash of the charge status indicator.

When the battery is fully charged the charge status indicator changes to light continuously.

If a fault is detected with a battery, or if the battery temperature is too high or too low for safe charging then the charge status indicator shows a fast flash.

LED colour and pattern	Status
Off	No battery in charge compartment.
Slow flash (one per one and half seconds) 	The battery is being charged.
Fast flash (five per second) 	There is a fault with the battery or it is too cold or too hot.
Continuous 	The battery is fully charged.

If the charger is located somewhere hot then it is possible that the additional heating of the battery whilst it is charged will cause the charger to indicate a fault on a battery. This will automatically clear once the battery cools down again. The battery charger adjusts the charge rate of each battery as necessary to attempt to avoid this from happening. As a result, if the charger is used in a warm location the batteries will take longer to charge. Keeping the charger in a cool location will ensure the fastest possible charge times.

If all four compartments of the charger are used then the charger itself will warm up. This causes it to slow the charge rate down. This means that charging four batteries will take longer than charging one, two or three batteries. Approximate charge times for fully discharged batteries, assuming an ambient temperature of 20°C are shown below:

Batteries being charged	Approximate charging time
Single EasyPack L	150 minutes
Single EasyPack XL	220 minutes
Two EasyPack L	160 minutes
Two EasyPack XL	315 minutes
Four EasyPack L	180 minutes
Four EasyPack XL	360 minutes

TROUBLESHOOTING AND MAINTENANCE

MAINTENANCE

For trouble-free service observe the following precautions when using the 1136 Battery Charger:

- Do not store or use the 1136 Battery Charger in any location that is dusty, damp, or wet.
- Do not attempt to use any other power supply than the recommended ones.
- Do not attempt to charge other types of battery.

TROUBLESHOOTING

Symptoms	Possible Cause	Action
The charger indicates a fault (fast flash)	The battery is too hot.	Leave the battery to cool down; the charger will automatically start to charge once the battery temperature falls.
		Move the charger to a cooler location.
	The battery is too cold.	Leave the battery to warm up; the charger will automatically start to charge once the battery temperature rises.
		Move the charger to a warmer location.
	The battery has a fault	Do not use the battery.
The charger indicates full charge (continuous indicator) after a short period of time.	The battery is already charged.	Use the battery.
	The battery has a fault.	Do not use the battery.
The charge status indicator does not light when a battery is inserted.	The charger is not powered.	Verify that the power supply is connected and powered. The blue power indicator on the front of the charger must be lit.
	The battery retaining clip is not in the correct location for the battery type.	Move the battery retaining clip to the correct location.
	The battery is not properly located.	Ensure the battery has been fully pushed into the compartment and is held by the hook on the battery retaining clip.
	The battery has a fault.	Do not use the battery.

TECHNICAL SPECIFICATIONS

SUMMARY OF SPECIFICATIONS

The following table summarises the 1136 Battery Charger's intended operating environment and technical hardware specifications:

Charging compatibility	
Compatible Power Supply	Must be used with Motorola PSU 50-14000-148R or PWRS-14000-148C (12V) and an IEC mains lead
Compatible Batteries	EasyPack™ L Rechargeable Li-Polymer battery
	EasyPack™ XL Rechargeable Li-Polymer battery
Charge time	Varies depending on the type and number of batteries, typical 150 minutes with a single EasyPack L to 360 minutes with four EasyPack XL.
Physical Characteristics	
Dimensions (maximum)	110 mm (w) × 110 mm (d) × 85 mm (h)
Dimensions (without battery retainer clips)	110 mm (w) × 110 mm (d) × 41 mm (h)
Weight (excluding optional steel base)	180 g (6.4 oz)
Enclosure material	GE Lexan Polycarbonate
Colour	Grey with black battery retainer clips.
Material finish	Sparked surface
User indication	Individual charge status indicator for each battery slot. Power on indicator
Environmental	
Operating Temperature	5°C to 40°C (41°F to 104°F)
Storage Temperature	-40°C to +70°C (-40°F to 158°F)
Humidity	Up to 90% Relative humidity Non Condensing
Drop specification	76.2 cm (30 inch) drops to vinyl tiled concrete at room temperature.
Electrostatic discharge	+/- 15kV air discharge, +/- 8kV direct discharge
Construction	RoHS compliant
Regulatory	
EMI/RFI	EN 61000-6-3:2007+A1:2011, EN 61000-6-1:2007
	Title 47 of the CFR:2010, Part 15 Subpart (b)
	ICES-003 Issue 4:2004
Electrical Safety	IEC 60950-1: 2nd Edition 2005; Am 1:2009 (National and group differences in accordance with CB Bulletin dated 2012-02-21) EN 60950-1:2006 + A11:2009 + A12:2011 AS/NZS 60950.1:2011 UL 60950-1 (CAN C22.2 CSA 60950-1) 2nd Edition, Amendment 1, December 19 2011. CAN/CSA-C22.2 No. 60950-1-07 (R2012)

REGULATORY INFORMATION

FCC

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference that may cause undesired operation.

Changes or modifications not expressly approved by the manufacturer could void the user's authority to operate this equipment.

INDUSTRY CANADA

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

Operation is subject to the following two conditions:

1. This device may not cause interference, and
2. This device must accept any interference, including interference that may cause undesired operation of the device.

CAUTION:

RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

USE ONLY THE CORRECT POWER SUPPLY. Use of an alternative power supply will invalidate any approval given to this device, void the warranty for the product and may be dangerous.

It is recommended that when the charger is not in use that the power supply is turned off and disconnected from the mains.

WASTE ELECTRICAL AND ELECTRONIC EQUIPMENT (WEEE)

For EU Customers: All products at the end of their life must be returned to TSL for recycling. For information on how to return product please contact TSL.

WARRANTY

(A) Warranty

TSL's hardware Products are warranted against defects in workmanship and materials for a period of twelve (12) months from the date of shipment, unless otherwise provided by TSL in writing, provided the Product remains unmodified and is operated under normal and proper conditions. Warranty provisions and durations on software, integrated installed systems, Product modified or designed to meet specific customer specifications ("Custom Products"), remanufactured products, and reconditioned or upgraded products, shall be as provided in the applicable Product specification in effect at the time of purchase or in the accompanying software license.

(B) Spare Parts

Spare parts (i.e. parts, components, or subassemblies sold by TSL for use in the service and maintenance of Products) are warranted against defects in workmanship and materials for a period of thirty (30) days from the date of shipment. Spare parts may be new or originate from returned units under the conditions set forth in subsection D below.

(C) Repair of TSL branded hardware

For repairs on TSL branded hardware Products under this Agreement, including repairs covered by warranty, the repair services provided are warranted against defects in workmanship and materials on the repaired component of the Product for a period of thirty (30) days from the shipment date of the repaired Product, or until the end of the original warranty period, whichever is longer. Any such defects shall be notified to TSL in writing within 7 days of the same becoming apparent.

(D) Product Service

Products may be serviced or manufactured with parts, components, or subassemblies that originate from returned products and that have been tested as meeting applicable specifications for equivalent new material and Products. The sole obligation of TSL for defective hardware Products is limited to repair or replacement (at TSL's option) on a "return to base (RTB)" basis with prior TSL authorisation.

Customer is responsible for prompt shipment to TSL and assumes all costs and risks associated with this transportation; return shipment to the Customer will be at TSL's expense. Customer shall be responsible for return shipment charges for product returned where TSL determines there is no defect ("No Defect Found"), or for product returned that TSL determines is not eligible for warranty repair. No charge will be made to Buyer for replacement parts for warranty repairs. TSL is not responsible for any damage to or loss of any software programs, data or removable data storage media, or the restoration or reinstallation of any software programs or data other than the software, if any, installed by TSL during manufacture of the Product.

(E) Original Warranty Period

Except for the warranty applying solely to the repaired component arising from a repair service as provided in Section C above, the aforementioned provisions do not extend the original warranty period of any Product that had either been repaired or replaced by TSL.

(F) Warranty Provisions

The above warranty provisions shall not apply to any Product:

- (i) which has been repaired, tampered with, altered or modified, except by TSL's authorized service personnel;
- (ii) in which the defects or damage to the Product result from normal wear and tear, misuse, negligence, improper storage, water or other liquids, battery leakage, use of parts or accessories not approved or supplied by TSL, or failure to perform operator handling and scheduled maintenance instructions supplied by TSL;
- (iii) which has been subjected to unusual physical or electrical stress, abuse, or accident, or forces or exposure beyond normal use within the specified operational and environmental parameters set forth in the applicable Product specification; nor shall the above warranty provisions apply to any expendable or consumable items, such as batteries, supplied with the Product.

EXCEPT FOR THE WARRANTY OF TITLE AND THE EXPRESS WARRANTIES STATED ABOVE, TSL DISCLAIMS ALL WARRANTIES ON PRODUCTS FURNISHED HEREUNDER INCLUDING ALL IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR USE. ANY IMPLIED WARRANTIES THAT MAY BE IMPOSED BY LAW ARE LIMITED IN DURATION TO THE LIMITED WARRANTY PERIOD. SOME STATES OR COUNTRIES DO NOT ALLOW A LIMITATION ON HOW LONG AN IMPLIED WARRANTY LASTS OR THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES OR CONSUMER PRODUCTS. IN SUCH STATES OR COUNTRIES, FOR SUCH PRODUCTS, SOME EXCLUSIONS OR LIMITATIONS OF THIS LIMITED WARRANTY MAY NOT APPLY.

The stated express warranties are in lieu of all obligations or liabilities on the part of TSL for damages, including but not limited to, special, indirect or consequential damages arising out of or in connection with the use or performance of the Product or service. TSL's liability for damages to Buyer or others resulting from the use of any Product or service furnished hereunder shall in no way exceed the purchase price of said Product or the fair market value of said service, except in instances of injury to persons or property.

TSL is not responsible for any damages incurred during shipment if the approved shipping container is not used. Shipping the units improperly can possibly void the warranty. If the original shipping container was not kept, contact your local distributor or TSL to have another sent to you.

TSL shall not be responsible for any injury, damage or loss of whatever kind caused directly or indirectly by the goods whether as a result of their manufacture, operation, use or otherwise and the customer shall indemnify TSL from any claim arising from any loss suffered by any third party.

ABOUT TSL

ABOUT

TSL designs and manufactures both standard and custom embedded, snap on and standalone peripherals for handheld computer terminals. Embedded technologies include:

- RFID - Low Frequency, High Frequency & UHF
- *Bluetooth®* wireless technology
- Contact Smartcard
- Fingerprint Biometrics
- 1D and 2D Barcode Scanning
- Magnetic Card Readers
- OCR-B and ePassport

Utilizing class leading Industrial design, TSL develops products from concept through to high volume manufacture for Blue Chip companies around the world. Using the above technologies TSL develops innovative products in a timely and cost effective manner for a broad range of handheld devices.

CONTACT

Address:	Technology Solutions (UK) Limited, Suite C, Loughborough Technology Centre, Epinal Way, Loughborough, Leicestershire, LE11 3GE. United Kingdom.
Telephone:	+44 (0)1509 238248
Fax:	+44 (0)1509 220020
Email:	enquiries@tsl.uk.com
Website:	www.tsl.uk.com



ISO 9001: 2008

© Technology Solutions (UK) Ltd 2013. All rights reserved. Technology Solutions (UK) Limited reserves the right to change its products, specifications and services at any time without notice.

The Netherlands



Elektrostraat 17
NL-7483 PG Haaksbergen

T: +31 (0)53 573 33 33
F: +31 (0)53 573 33 30
E: nl@texim-europe.com

Belgium



Zuiderlaan 14 bus 10
B-1731 Zellik

T: +32 (0)2 462 01 00
F: +32 (0)2 462 01 25
E: belgium@texim-europe.com

UK & Ireland



St. Mary's House, Church Lane
Carlton Le Moorland
Lincoln LN5 9HS

T: +44 (0)1522 789 555
F: +44 (0)845 299 22 26
E: uk@texim-europe.com

Germany North



Bahnhofstrasse 92
D-25451 Quickborn

T: +49 (0)4106 627 07-0
F: +49 (0)4106 627 07-20
E: germany@texim-europe.com

Germany South



Martin-Kollar-Strasse 9
D-81829 München

T: +49 (0)89 436 086-0
F: +49 (0)89 436 086-19
E: germany@texim-europe.com

Austria



Warwitzstrasse 9
A-5020 Salzburg

T: +43 (0)662 216 026
F: +43 (0)662 216 026-66
E: austria@texim-europe.com

Nordic region



Sdr. Jagtvej 12
DK-2970 Hørsholm

T: +45 88 20 26 30
F: +45 88 20 26 39
E: nordic@texim-europe.com

General information



info@texim-europe.com
www.texim-europe.com